

Additional Repair Instruction - Frame Section -



- 1.) To remove the frame, drill out the rivets frame is connected to. Bottom frames, remove the frame protector first before pulling the frame out.
- 2.) When inserting the new frame, make sure the hole on the frame aligns with the hole on the corner. You can use a pick tool to gently wiggle and align the holes.